HOW TO CHANGE BATTERIES

Unscrew the screw located on the battery cover to take off the cover.
Locate button cell batteries LR44.
Make sure +, is in correct position.
Batteries included in this product are testing purpose only.
However, they can be used around 2 months.
When the unit has any problem, please change 2 batteries.

YOU NEED TO RESET WHEN YOU HAVE FOLLOWING CONDITIONS.

- The screen is not in stable condition.
- If you want to change the way to raise GYAOPPI.
- When you play the first time.
- When batteries were changed.

CHECKING SUPER GYAOPPI'S CONDITION

Press the A button to change to check mode, then press button B to see Gyaoppi's age and weight.
Press again to view if he's hungry and his happiness level.
Press again to check his behaviour level and amounts of sleep.
Check your Super Gyoappi's condition regularly.

CAUTION

• Take special care to ensure batteries are inserted correctly, observing (+) and (-) marks on battery and product • Removal and replacement of batteries should be carried out by an adult or under adult supervision • Do not attempt to recharge non rechargeable batteries. • Rechargeable batteries must be removed from toy before recharging • Removal and recharging of rechargeable batteries should be carried out by an adult or under adult supervision • Avoid short circuiting the contacts in the battery compartment or the battery terminals. • Remove exhausted batteries from product • Do not mix old (used) and new batteries or batteries of different types eg. rechargeable and alkaline • Do not attempt to power battery products by the introduction of mains supply or separate power supplies, and do not attempt to plug any part of this product into the mains supply • Dispose of exhausted batteries safely, and never dispose of batteries in a fire • Remove batteries from product after use or if storing for long periods • Periodically examine product for signs of damage to electrical parts and do not play with until damage has been properly examined • Only use batteries of the same or equivalent type to those recommended. • Please retain the above information for future reference.

USE OF RE-CHARGEABLE BATTERIES IS NOT RECOMMENDED FOR THIS PRODUCT

• TOMY RECOMMEND DURACELL BATTERIES •

SUPER GYAOPPI 9 IN 1 28 BIT

HOW TO SET ALARM

When A and B button are pressed simultaneously during the CLOCK MOD the screen will change to SET MODE. You can adjust HOUR by pressing button and to adjust MINUTES, press B button.Then press C button change to ALARM SETTING MODE. Repeat the above mentioned steps set alarm.
Press C button to return to CLOCK MODE.

If A button and C button are pressed simultaneously for 5 seconds, GYAOPI will grow up 60 times faster than normal. If you want to return to origin press A button and B button simultaneously for 4 second.

MEMORY FUNCTION

When A, B and C buttons are pressed simultaneously for 5 second, the screen will show MEMORY MODE. You can see all kinds of GYAOPPI raised in past on the screen.
(You will see species, its age in order.)

When B button is pressed during the GYAOPPI mode, the screen will change to CLOCK MODE.
A button: change clock to alarm
B button: change GYAOPPI mode to clock
C button: change on / off of alarm function

OTHER FUNCTIONS

All function should be done during the GYAOPPI MODE.

on / off sound: press A and C simultaneously.

pose function: press A and C button simultaneously for 5seconds.To turn off this function, repeat the same step.
(Be noted that there are no changes on the screen.)

New Super Gyaoppi is a major improvement. Here are the super features.

Super Feature 1: 9 in 1
There are 9 Gyaoppies to care for: A dog, cat, dinosaur, panda, bear, a chicken,penguin, frog, duck, and an alien!!
Super Feature 2: Alarm Clock Function
Super Feature 3: Memory Function:
In this game Gyaoppi changes shape every day!And you can see all of his different forms - past and present - all 500 of them!
Super Function 4: Pause Function
You can use this function when you can not take care of GYAOPPI.Screen and time will not stop but GYAOPPI'S growth will stop.
Do not forget to turn off this function later.

HOW TO PLAY GYAOPPI

1.First, to activate unit, pull out isolation tape.(If you ca... not see anything on the screen,press reset button on the back of the unit.)
2.Select GYAOPPI you want raise by pressing button A. Then press button B to enter. ※ After you press Button B, screen will show GYAOPPI. However, GYAOPPI will not be born without setting the clock.
3.Press B button again to change to clock mode.
4.Press A button to set HOUR, and press B button to set MINUTES.Then press C button to enter.
5.After hours and minutes were set by pressing C button,the screen will change to ALARM TIME SET mode.If you want to set alarm,please repeat step 4.
6.Press C button to return to time mode then press B button to return to GYAOPPI mode.



How to care for your Super Gyaoppi

WHEN GYAOPPI IS ON THE SCREEN, USE A-BUTTON TO SELECT "TAKE-CARE MODE"

FOOD
When GYAOPPI is hungry, select this sign and feed to GYAOPPI.Make sure to feed him some snacks and water."But be careful, he might get sick if you overfeed him or not give him enough water"

GAME A
ESCAPE GAME.This is a game to escape from falling objects.A button is to move to the left and B button is for the right."If you successfully escape from all the falling objects,Gyaoppi gets happier."

INJECTION
When you see ☠ sign, GYAOPPI is ill
Please give him injections until sign is off.

BEHAVIOUR
"When Gyaoppi is selfish or calls you for attention with no reason, he may need disciplinning.If you discipline him when it's really necessary, his behaviour points will increase. Discipline Gyaoppi for no reason and his discipline level will decrease.The objective is to raise a well balanced and disciplined Gyaoppi!"

GAME B
This is a game to guess the number whether the number is larger than 7 or not."If Gyaoppi wins more of the 5 Games than he loses then he gets Happier."

WEATHER
When weather is fine and sun beam is too strong,give GYAOPPI a hat.If it is rainy, give him an umbrella.If you do not take care of him right, he may get sick.

CLEAN UP
"When Gyaoppi leaves a mess, choose this sign to clean up immediately - otherwise he may become ill.

CHECK
When you select this function, you will see your Gyaoppi's age, and weight displayed - as well as his happiness, behaviour and hunger levels.

LAMP
When GYAOPPI is sleeping, select this sign to turn off the lamp.If you turn off the lamp GYAOPPI will sleep.If amount of sleep is not enough, take some nap.